



EZ-ON

EZ-ON PRODUCTS

1-800-323-6598

www.ezonpro.com

86Y

IMPORTANT INFO

- Meets FMVSS213.
- 86Y is for use by a passenger weighing 66 – 168lbs.
- You must use EZ-ON hardware tether kit (included) to install this conversion vest if the factory installed tether anchor weight limit is less than the weight of the passenger or if there is no tether anchor point available in your vehicle.
- Register this product to be notified for a safety recall.

WARRANTY

EZ-ON Products stands behind the products we make. Warranty covers any defects in material or workmanship under normal use during the warranty period. We will repair or replace product defects for 1 year from manufacturer date.

WARNING

Death or serious injury can occur if manufacturer's instructions are not followed correctly. All EZ-ON products are dynamically tested to meet NHTSA standards. Please follow washing instructions on product tag. Replace product if it is damaged, frayed, or has been in a crash. Recommended replacement after six years. EZ-ON Products are not liable for injury if these recommendations are not followed.

EMERGENCY RELEASE PROCEDURE

When evacuating a passenger in an 86Y belt, one cut of the lap belt will allow the passenger to evacuate the vehicle.

CUT ALONG DOTTED LINE FOR EMERGENCY RELEASE



100 SCBC
EZ-ON Safe Cut
Belt Cutter





86Y

INSTALLATION INSTRUCTIONS



1. Locate the tether anchor bracket.

**Check the vehicle owner's manual to locate factory installed tether bracket.*

**86Y tether strap can be turned one half twist to snap on difficult anchor locations.*

2. Connect tether hook to tether anchor bracket directly behind passenger. 20 degrees from "Y" center is acceptable.

3. Place the Y-bridge on the seat top. Rest black shoulder straps on the front of the seat.

4. Adjust tilt lock adjuster to remove excess webbing so Y-bridge sits on seat top.

5. Place the adjustable belt straps over each shoulder of the passenger.

6. Allow the belt loop ends to lay on the passenger's lap.

7. Thread the vehicle lap only belt across the lap and through each belt loop.

8. Buckle lap belt low across the lap and reduce the lap belt slack.

9. To shorten or lengthen the shoulder vest straps slide the webbing up or down through the adjuster. Keep both adjusters as close to the shoulders as possible.

WARNING: Do not shorten the belt length too much as this could pull the lap belt up and over the stomach which might cause injury.

10. Secure the chest clip keeping the clip below the vest adjusters at arm pit level.